



- 1 LIFTING DEVICE
- 3 EXHAUST ELBOW FOR HOSE I.D 89
- 4 AIR FILTER
- 5 OIL FILLING
- 6 OIL DIPSTICK ENGINE
- 7 OIL FILTER
- 8 OIL DRAIN FOR PUMP, ENGINE
- 9 OIL DIPSTICK REVERSE GEAR
- 10 OIL FILLER CAP REVERSE GEAR
- 11 OIL DRAIN FOR PUMP, REVERSE GEAR
- 12 WATER INLET FOR HOSE I.D 32
- 13 SEA WATER PUMP
- 14 WATER FILLER CAP FRESH WATER
- 15 HEAT WATER OUTLET
- 16 HEAT WATER INLET
- 17 FUEL CONNECTION FOR HOSE I.D 9
- 18 FUEL RETURN CONNECTION FOR HOSE I.D 9
- 19 FUEL FILTER
- 20 SPEED CONTROL LEVER
- 21 CONNECTION BOX FOR EXTENSION CABLE
- 22 BATTERY MINUS (-) CONNECTION
- 23 PLUS (+) CONNECTION FOR CHARGING DISTRIBUTOR
- 24 STARTER BATTERY PLUS (+) CONNECTION
- 25 GEAR SHIFT CONTROL CABLE
- 26 AIR INLET SILENCER
- 27 WATER DRAIN, FRESH WATER
- 28 WATER DRAIN, SEA WATER
- 29 THROTTLE CONTROL CABLE

SCALE 1:5

<p>The copying, distribution and utilization of this document as well as the completion of its contents is allowed without restriction for the purpose of maintenance, operation and repair of the equipment of the company, and is prohibited for the rest of the world of patent, utility model or trademark registration.</p>	<p>SYMBOLS, DESIGNATIONS AND GENERAL DRAWING METHODS STD 101-0005</p>	
	<p>Document title ENGINE INSTALLATION D2-60, D2-75 / MS25A</p>	
	<p>Document type INSTALLATION DRAWING Cover design: Document practice</p>	
<p>Document No 3590972</p>	<p>Issue index 03</p>	<p>Sheet No 1(11)</p>

